

HOW TO...

Measure for Pew Seat Cushions



Start by measuring, along the back of the pew seat, the length from end to end within the arm rests. Then measure the depth of the seat from the very front edge to the back. Also, as seen in the inset illustration, measure the thickness of the seat at the front edge.

If needing cushions for the backs of pews, measure from the bottom, where it meets the seat, up to the top rail. (4)

Along with the measurements, please send photographs detailing these areas so that we can familiarize ourselves with your particular pews, and possible applications.

**ATTENTION: On measurement #2, if you are measuring for our regular pew form cushions, measure from the back of the seat forward to just before the seat starts to curve down. However, for our drop-front cushions, measure from the back of the seat forward to the furthest most edge of the seat.